





User Manual

- 1. To switch on the unit, turn the knob clockwise on the top panel of the unit. You can use the same knob to adjust the volume of the unit.
- 2. To move from one sound to another; Press the 'M' button once.
- 3. To play any particular sound in loop for 15/30/60 mins; Press the 'Timer setting' button to set respective time duration of the sound playout. 'Timer indicator led' will indicate the same.

Note: The unit will turn off automatically once the playout is completed for the set duration.

- 4. Charging indicator:
 - a. Steady Red light: Unit is being charged.
 - b. Light turns off: Unit is fully charged.